

MAINTENANCE ON FIRST FLUSH WATER DIVERTERS

A First Flush Water Diverter captures those first, and most contaminated drops of rain and prevents them from entering the rainwater tank.



Ensure the outlet of the diverter is clear of any debris. If the outlet is blocked, the chamber will not empty and the first flush of water will not be diverted when it rains.

Periodically unscrew the End Cap of the water diverter to allow any debris to fall out.

Hose or wash the Filter Screen if required and clean the Flow Control Valve, then replace.

Good-quality water will help extend the life of your pumps and appliances.

For further information please
contact 1800 06 77 44